

Version-E100930

D-LC

Rundeteller



ALGE-TIMING

Manual

Important Information

General

Before using your ALGE-TIMING device read the complete manual carefully. It is part of the device and contains important information about installation, safety and its intended use. This manual cannot cover all conceivable applications. For further information or in case of problems that are mentioned not at all or not sufficiently detailed, please contact your ALGE-TIMING representative. You can find contact details on our homepage www.alge-timing.com

Safety

Apart from the information of this manual all general safety and accident prevention regulations of the legislator must be taken into account.

The device must only be used by trained persons. The setting-up and installation must only be executed according to the manufacturer's data.

Intended Use

The device must only be used for its intended applications. Technical modifications and any misuse are prohibited because of the risks involved! ALGE-TIMING is not liable for damages that are caused by improper use or incorrect operation.

Power supply

The stated voltage on the type plate must correspond to voltage of the power source. Check all connections and plugs before usage. Damaged connection wires must be replaced immediately by an authorized electrician. The device must only be connected to an electric supply that has been installed by an electrician according to IEC 60364-1. Never touch the mains plug with wet hands! Never touch live parts!

Cleaning

Please clean the outside of the device only with a smooth cloth. Detergents can cause damage. Never submerge in water, never open or clean with wet cloth. The cleaning must not be carried out by hose or high-pressure (risk of short circuits or other damage).

Liability Limitations

All technical information, data and information for installation and operation correspond to the latest status at time of printing and are made in all conscience considering our past experience and knowledge. Information, pictures and description do not entitle to base any claims. The manufacturer is not liable for damage due to failure to observe the manual, improper use, incorrect repairs, technical modifications, use of unauthorized spare parts. Translations are made in all conscience. We assume no liability for translation mistakes, even if the translation is carried out by us or on our behalf.

Disposal

If a label is placed on the device showing a crossed out dustbin on wheels (see drawing), the European directive 2002/96/EG applies for this device.

Please get informed about the applicable regulations for separate collection of electrical and electronic waste in your country and do not dispose of the old devices as household waste. Correct disposal of old equipment protects the environment and humans against negative consequences!

Copyright by ALGE-TIMING GmbH

All rights reserved. Any duplication, either in full or in part, requires the prior written consent of the copyright holder.

Innhold

| | | |
|------|----------------------------------|---|
| 1. | Tilgjengelige komponenter | 3 |
| 2. | Funksjoner | 3 |
| 2.1. | Bytt mellom Tell-OPP og Tell-NED | 3 |
| 2.2 | Tell-OPP (00) | 4 |
| 2.3 | Tell-NED (99) | 4 |
| 3. | Strømforsyning | 4 |

1. Tilgjengelige komponenter

Tavle med 1, 2 eller 3 siffer. Enkel-, dobbel- eller trippel-sidig, og innebygd batteripakke og lader.

Manuell håndbryter 023-02.

Stativ for rundeteller (TRI128 eller TRIMAN, avhengig av modell/størrelse).

Nettkabel (for å lade batteripakken)

Bjelle (kun på type D-LCB)

2. Funksjoner

Tell-OPP: tell opp fra 0

Tell-NED: tell ned fra en satt verdi

2.1 Bytt mellom Tell-OPP og Tell-NED

Fra Tell-OPP til Tell-NED:

Display må vise 0 – enten etter at det er slått på, eller etter reset og påfølgende holding av trykknappen i minst 5 sek. til tavlen vise 0

Trykk håndbryteren helt til 99 er vist på display (det første sifferet blinker)

Fra Tell-NED til Tell-OPP:

Display må vise den satte start-verdi - enten etter at det er slått på, eller etter reset og påfølgende holding av trykknappen i minst 5 sek. til tavlen vise 99

Trykk håndbryteren helt til 0 er vist på display

2.2 Tell-OPP (0)

- Display viser 0
- Trykk håndbryteren kort – display teller opp med 1
- Trykk håndbryteren i 3 sekunder og slipp – display teller ned med 1
- Resett til null ved å trykke håndbryteren i 5 sekunder (NB! Dersom resett gjøres når display allerede viser 0, skifter display til telle-modus Tell-NED)

2.3 Tell-NED (99)

- Display viser 99 (første siffer blinker)
- Sett ønsket verdi i det blinkende sifferet ved å trykke håndbryteren nødvendig antall ganger
- Trykk håndbryteren i 3 sekund og slipp. Neste siffer blinker.
- Gjør det same til alle siffer er satt.
- Displayet viser nå start-verdien, og ingen siffer blinker lenger.
- Trykk håndbryteren kort – display teller ned med 1
- Trykk håndbryteren i 3 sekunder og slipp – display teller opp med 1
- Resett til start-verdien ved å trykke håndbryteren i 5 sekunder (NB! Dersom resett gjøres når display allerede viser start-verdien, skifter display til telle-modus Tell-OPP)

3. Strømforsyning

Rundetelleren har en integrert batteripakke og lader, som forsyner den med strøm i ca. 15 timer sammenhengende bruk.

For å full-lade batteriene, må rundetelleren være tilknyttet strømmettet i 14 timer.

OBS ! Dersom rundetelleren ikke er i bruk på 10 minutter, går den over i spare-modus (tavlevising forsvinner). Trykk håndbryteren en gang for å aktivere rundetelleren til tidligere oppsett.